




Contents

Spare Parts		
		Page
Ringfeder Couplings	2020G	E 2
	65G/150	E 3
	4040G150B	E 4
	5050-B-NZ	E 5
	5055-NZ	E 6
	5050G5	E 7
	80G5	E 8
	Kits & Accessories	E 9
	5050 AM/RL	E 10

Copyright © TWL. The illustrations, information and specifications contained within this catalogue remain the property of TWL. No part of this catalogue may be reproduced in whole or in part without prior approval. While all care has been taken in the production of this catalogue, no responsibility for errors, omissions or variations will be accepted. Photography, descriptions and references are subject to change without notice.




SPARE PARTS > RINGFEDER > 2020G



2020G PARTS LIST		
Item	Description	Part Number
2	Cap	14 995 340
3	Hand / Locking Lever	14 995 284
8	Coupling Bolt	14 995 324
9	Locking Spring	14 995 428
10	Safety Bolt	14 995 292
13	Wearing Plate	14 995 332


SPARE PARTS > RINGFEDER > 65G/150



65G/150 PARTS LIST			
Item	Type	Part Number	Description
2	125-150	07 995 849	Counter clutch
3	125-150	12 995 172	Plate spring
4	125-150	06 998 526	Hook locking compl.
5	125-150	10 998 921	Bolt
8	125-150	06 998 500	Bolt compl.
13	125-150	10 996 180	Link bolt compl.
36	125	07 998 295	Rubber spring (2 pcs.)
36	135	07 998 309	Rubber spring (2 pcs.)
36	140-150	07 998 317	Rubber spring (2 pcs.)
37	125	07 995 547	Thrust washer
37	135	07 995 539	Thrust washer
37	140-150	07 995 520	Thrust washer
38	125	01 996 770	Drawbar guide compl.
38	135	00 990 531	Drawbar guide compl.
38	140	00 990 540	Drawbar guide compl.
38	150	00 990 558	Drawbar guide compl.
39	125	10 995 302	Bearing bush (2 pcs.)
39	135	10 995 310	Bearing bush (2 pcs.)
39	140-150	10 996 732	Bearing bush (2 pcs.)
40	125	07 995 512	Tension washer
40	135	07 995 687	Tension washer
40	140-150	07 995 555	Tension washer
41	125	10 995 299	Spring washer B 30, DIN 137
41	135	10 995 248	Spring washer B 36, DIN 137
41	140-150	10 996 686	Spring washer B 45, DIN 137
42	125	06 997 759	Castellated nut M 30 compl.
42	135	06 997 740	Castellated nut M 36x3 compl.
42	140-150	06 997 732	Castellated nut M 35x3 compl.
43	125	10 998 433	Cotter pin 6,3x50 DIN 94, St, A3C
43	135	12 991 550	Cotter pin 6,3x63 DIN 94, St, A3C
43	140-150	12 991 533	Cotter pin 8x80 DIN 94, St, A3C
44	125	10 996 678	Protecting cap
44	135	10 996 660	Protecting cap
44	140-150	10 991 463	Protecting cap

SPARE PARTS > 4040G150B

OBSOLETE MODEL




4040G150B PARTS LIST		
Item	Part Number	Description
2	14 991 240	Top guide bush
3	14 991 248	Coupling body cpl., with safety device design A
3a	14 991 720	Coupling body cpl., with manual safety device design B-msd
4	14 994 478	Safety device, complete design A
4a	14 991 073	Manual safety device, complete (14 996 434)
6	14 991 256	Bottom guide bush
7	06 998 771	Special plastic plate, cpl.
7a	14 994 503	Wear plate, cast iron
11	07 995 563	Return spring
12	14 991 264	Tab washer, complete
15	14 991 272	Hand lever-/locking lever combination, design A
15a	14 991 312	Hand lever design A
18	07 998 341	Spring arm (2 pcs.)
23	14 991 280	Coupling bolt, cpl. with locking springs short, L = 75 mm
25	14 991 241	Locking spring short, L = 75 mm (2 pcs.)
26	14 991 288	End cap, cpl.

4040G150B PARTS LIST		
Item	Part Number	Description
32	14 991 359	Hexagon screw M 10x115- 10.9
36	14 991 672	Rubber spring (2 pcs.)
37	07 995 520	Thrust washer
38	14 991 296	Bar guide cpl.
39	14 991 304	Bearing bush (2 pcs.)
40	07 995 555	Tension washer
42	06 997 732	Castellated nut M 45x3, cpl.
43	12 991 533	Cotter pin 8 x 80 DIN 94, St, A3C
44	10 991 323	Protecting cap
45	14 991 368	Hand lever-/locking lever combination, design B
45a	14 997 190	Hand lever design B
48	09 127 100	Plug for sensor hole (10 pcs.)
52	14 991 320	Axle with locking lever
	14 991 328	Repair kit 4040 / 4045 A, B, coupling bolt, cpl. (23), special plastic plate, cpl., top guide bush, bottom guide bush, cotter pin

SPARE PARTS > 5050-B-NZ

OBSOLETE MODEL




Repair kit

5050-B-NZ PARTS LIST		
Item	Description	Part Number
2	Top guide bush	14 991 384
3	Coupling body	14 991 760
4	Manual safety device (14996434)	14 991 073
6	Bottom guide bush	14 991 407
7	Special plastic plate	6 998 321
7a	Wearing plate (cast iron)	9 996 770
11	Return spring	7 995 610
12	Tab washer	14 991 399
18	Spring arm	7 998 341
23	Coupling bolt	14 991 375
25	Locking spring	14 991 273
26	End cap, cpl. (14 997 511)	14 991 367
32	Hexagon screw M10 x 115, 10.9	14 991 359
36	Rubber spring	14 994 568
37	Thrust washer	14 994 472
38	Bar guide	14 994 463

5050-B-NZ PARTS LIST		
Item	Description	Part Number
39	Bearing bush	14 994 876
40	Tension washer	14 994 496
42	Castellated nut M45 x 3	6 997 732
43	Cotter pin 8 X 80	12 991 533
44	Protecting cap	14 994 455
45	Hand-/locking lever combination design B	14 996 858
45a	Hand lever bended, design B	14 997 190
48	Plug for sensor hole (10 Pieces)	9 122 900
52	Axle with locking lever	14 996 842
98	Sealing incl. grease plugs	9 177 600
99	Grease plug (10 pieces)	9 177 500
	Repair Kit (Pos. 2 + 6 + 7 + 23 + 43)	14 991 632

SPARE PARTS > 5055-NZ

OBSOLETE MODEL




5055-NZ PARTS LIST		
Item	Description	Part Number
2	Top guide bush	14 995 463
3	Coupling body	14 991 247
4	Safety device	14 994 478
6	Bottom guide bush	14 991 239
7	Wearing plate (cast iron)	14 991 255
11	Coupling mechanism design A - without sensor	14 991 263
14	Return spring	14 994 529
15	Hand-/locking lever combination design A	14 991 391
15a	Hand lever design A	14 991 312
18	Spring arm	7 998 341
23	Coupling bolt	14 991 279
25	Locking spring	14 991 273
26	End cap	14 991 367
32	Hexagon screw M10 x 115, 10.9	14 991 359

5055-NZ PARTS LIST		
Item	Description	Part Number
35	Plastic covers for mechanism	14 991 287
36	Rubber spring	14 994 568
37	Thrust washer	14 994 472
38	Bar guide	14 994 463
39	Bearing bush	14 994 876
40	Tension washer	14 994 496
42	Castellated nut M45 x 3	6 997 732
43	Cotter pin 8 X 80	12 991 533
44	Protecting cap	14 994 455
48	Plug for sensor hole (10 Pieces)	9 122 900
52	Axle with locking lever	14 991 383
80	Sensor	14 991 406
	Conversion kit for model AP	14 991 341
	Repair Kit (Pos. 2 + 6 + 7 + 23 + 43)	14 991 237

SPARE PARTS > 5050G5

OBSOLETE MODEL




5050G5 PARTS LIST		
Item	Description	Part Number
2	Top Guide Bush	14 991 384
3	Coupling Body	14 991 392
4	Safety Device	14 994 478
6	Bottom Guide Bush	14 991 407
7	Special Plastic Plate	06 998 321
7a	Wear Plate (cast iron)	09 996 770
11	Return Spring	07 995 610
12	Tab Washer	14 991 399
15	Hand-/ Locking Lever Combination Design A	14 991 391
15a	Hand Lever Design A	14 991 312
18	Spring Arm (2 pieces)	09 998 341
23	Coupling Bolt	14 991 375
25	Locking Spring (2 pieces)	14 991 273
26	End Cap	14 991 367

5050G5 PARTS LIST		
Item	Description	Part Number
32	Hexagon Screw M10 x 115, 10.9	14 991 359
36	Rubber Spring	14 991 672
37	Thrust Washer	07 995 520
38	Bar Guide	14 991 296
39	Bearing Bush	14 991 304
40	Tension Washer	07 995 555
42	Castellated Nut M45 x 3	06 997 732
43	Cotter Pin	12 991 533
44	Protecting Cap	10 991 323
45	Hand-/ Locking Lever Combination Design B	14 991 262
45a	Hand Lever Design B	14 991 376
48	Plug for Sensor Hole	09 127 100
52	Axle with Locking Lever	14 991 383
	Repair Kit (Pos. 2 + 6 + 7 + 23 + 43)	15 990 016

SPARE PARTS > 80G5

OBSOLETE MODEL




80G5 PARTS LIST		
Item	Description	Part Number
2	Top Guide Bush	7 998 210
3	Coupling Body	6 990 479
4	Safety Device	13 998 035
6	Bottom Guide Bush	7 998 252
7	Special Plastic Plate	6 998 321
11	Return Spring	7 995 601
12	Tab Washer	7 995 598
15	Hand / Locking Lever Design A	6 990 452
17	Bolt for Spring Arm	10 991 390
18	Spring Arm	7 998 341
23	Coupling Bolt	6 990 460
24	Locking Lever Pin	12 991 460
25	Locking Spring	13 992 274

80G5 PARTS LIST		
Item	Description	Part Number
26	End Cap	6 991 645
36	Rubber Spring	7 998 317
37	Thrust Washer	7 995 520
38	Bar Guide	990 558
39	Bearing Bush	10 996 732
40	Tension Washer	7 995 555
41	Spring Washer	10 996 686
42	Castellated Nut	6 997 732
43	Cotter Pin	12 991 533
44	Protecting Cap	10 991 463
45	Hand / Locking Lever Design B	6 991 661
	Repair Kit (Pos. 2 + 6 + 7 + 23 + 43)	13 994 277

SPARE PARTS > RINGFEDER KITS & ACCESSORIES

14 999 577 Duomatic Air Operated Coupling Kit



14 999 577 AIR OPERATED COUPLING KIT PARTS LIST


Item	Description	Part Number
	Kit Part No. (Pos. 1 + 2 + 3)	14 999 577

14 996 031 Valve Box

- Part No. 14 996 031



SPARE PARTS > RINGFEDER 5050 AM/RL



5050 AM/RL PARTS LIST		
Item	Description	Part Number
2	Top Guide Bush	14 991 384
3	Coupling Body	14 991 392
4	Safety Device	14 994 478
6	Bottom Guide Bush	14 999 501
7	Wearing Plate Kit	14 999 500
11	Return Spring	7 995 610
12	Tab Washer	14 991 399
15	Hand / Locking Lever Combination Design A	14 991 391
15a	Hand Level Design A/AM	14 991 312
18	Spring Arm (2 Pieces)	7 998 341
23	Coupling Bolt	14 991 375
25	Locking Spring (2 Pieces)	14 991 273
26	End Cap 5050 A/B, 5055 AM, Cpl. AM Unit	14 991 390
26 d	Plug (10 Pieces as Spare Part)	9 122 400
26 l	Shaft	14 991 269
	Membrane Kit for AM Unit	14 991 245

5050 AM/RL PARTS LIST		
Item	Description	Part Number
32	Hexagon Screw M10 x 115, 10.9	14 991 359
36	Rubber Spring	13 997 942
37	Thrust Washer	13 994 632
38	Bar Guide	14 994 916
39	Bearing Bush (2 Pieces)	14 994 876
40	Tension Washer	7 995 555
42	Castellated Nut M45 x 3	6 997 732
43	Cotter Pin 8 x 80	12 991 533
44	Protecting Cap	10 991 323
48	Plug for Sensor Hole A/B	09 127 100
52	Axle with Locking Lever	14 991 383
80	Sensor	14 991 406
80 a	Sensor Wedge	09 116 800
	Control Unit with LED	14 991 665
	Repair Kit (Pos. 2 + 6 + 7 + 23 + 43)	14 999 502

14 999 655 + 14 999 577 = 5050 NZAMD*

14 999 655 + 14 996 031 = 5050 NA AM*

*Note: A valve is needed to fit the above:
Part No. 5050 AM-VALVEKIT

